

EXPERT SP3000

ELECTRICAL SPOT CLEANING GUN



SP-3000



**ALBATROSS[®] USA
INC**

Est. 1898

36-41 36th Street
Long Island City, NY 11106
Tel: 718-392-6272

5439 San Fernando Road W.
Los Angeles, CA 90039
Tel: 818-543-5850

800-233-4468 • Fax: 718-392-2899 • www.albatross-usa.com

DIRECTIONS

- 1- Fill jar with non-flammable Cleaning Fluid.
2. Volume adjuster on side of gun has been pre-set for maximum pressure and minimum fluid consumption. To increase volume turn adjuster counter clockwise to decrease, turn clockwise.
3. Place absorbent pad under soiled material or garment. (Albatross Cleaning Station will provide best cleaning surface and will exhaust all fumes while drying cleaned area).
4. Hold fabric or garment directly in front of spray nozzle at a distance of two or four inches.
5. Depress trigger of gun to activate mechanism. Gun will blast fluid through nozzle at high pressure and will clean soiled area.
6. SP-3000 is equipped with an adjustable spray nozzle. Once soiled area is cleaned with pinpoint spray pattern adjust nozzle by turning counter clockwise to achieve varied spray pattern which "feathers out" cleaned area and prevents "ringing."

SP-3000 Cleaning gun will clean all materials or garments from delicate silks and polyester to wools and tight woven. Simply adjust variable spray nozzle to achieve desired pressure and spray pattern.

Use only Albatross non Flammable Cleaning solvents. These fluids are nonflammable and compatible with the pump mechanism. Flammable liquids, corrosive materials and water are not recommended for use in the expert SP-3000. If you are unsure of a particular liquid to be used in the gun, call Albatross at 1-800-233-4468 prior to use.

CAUTION: Use in a well-ventilated area with protection. Do not use flammable liquids.

SPARE PARTS LIST

POS.	PART NO.	DESCRIPTION
1.	6112	Gun housing A
2.	6111	Gun housing B
3.	6113	Coil (110V, 60Hz)
3.	6113-220	Coil (220V, 50Hz)
4.	6114	Trigger Switch
5.	6115	Armature
6.	6116	Electric Cord
7.	6117	Armature Spring
8.	6118	Volume Control Knob
9.	6119	Volume Control Spring
10.	6120	Bolt A
11.	6121	Bolt B
12.	6122-A/B	Gun unit locking screw
13.	6123	Pump cylinder
14.	6124	Piston
15.	6125	Piston spring
16.	6125	Stator
17-19.	6127-28-29	Valve complete
20.	6130	Container
21.	6131	Suction pipe
22.	6132	Pump unit locking screw
23.	6133	Terminal block
24.	EX400	Adjustable nozzle complete
Optional Accessories		
	5001	Albatross Gun Reel
	6108	Air Dryer Attachment
	6109	Direct feed Attachment

